


**ANNULLA E SOSTITUISCE  
IL CORRISPONDENTE  
ESPLOSO IN VS. POSSESSO**



| Pos | Codice        | Italiano       | English        | Francais       | Deutsch       | Espanol        |
|-----|---------------|----------------|----------------|----------------|---------------|----------------|
| 01  | <b>SY1025</b> | INVOLUCRO      | CASING         | ENVELOPPE      | GEHAEUSE      | ENVOLTURA      |
| 02  | <b>SY1001</b> | ETICHETTA      | LABEL          | ETIQUETTE      | AUFKLEBER     | ETIQUETA       |
| 03  | <b>SY1002</b> | GEMMA ROSSA    | RED LENS       | LENTILLE ROUGE | LINSE ROT     | PILOTO ROJO    |
| 04  | <b>SY1026</b> | COPERTURA      | COVER          | COUVERTURE     | VERSCHLUSS    | REVESTIMIENTO  |
| 05  | <b>SY1027</b> | CORPO          | SHELL          | CORPS          | KOERPER       | CUERPO         |
| 06  | <b>SY1005</b> | MAGNETE        | MAGNET         | AIMANT         | MAGNET        | MAGNETO        |
| 07  | <b>SY1006</b> | LEVA           | LEVER          | LEVIER         | HEBEL         | PALANCA        |
| 08  | <b>SY1007</b> | MANIGLIA       | HANDLE         | POIGNEE        | GRIFF         | MANILLA        |
| 10  | <b>SY1009</b> | ASSIEME SCHEDA | BOARD ASSEMBLY | FICHE COMPLETE | PLATINE KPL.  | FICHA COMPLETA |
| 11  | <b>SY1010</b> | TASTO          | PUSH BUTTON    | POUSOIR        | TASTE         | TECLA          |
| 12  | <b>SY1011</b> | PROLUNGA       | EXTENSION      | RALLONGE       | VERLAENGERUNG | PROLONGACION   |
| 13  | <b>SY1012</b> | MANOPOLA       | KNOB           | BOUTON         | KNOPF         | MANDO          |
| 15  | <b>SY1014</b> | PERNO          | PIN            | PIVOT          | STIFT         | PERNO          |
| 16  | <b>SY1015</b> | MOLLA          | SPRING         | RESSORT        | FEDER         | MUELLE         |
| 17  | <b>SY1016</b> | MOLLA          | SPRING         | RESSORT        | FEDER         | MUELLE         |
| 18  | <b>SY1017</b> | PIEDINO        | FOOT           | PIED           | FUSS          | PIE            |
| 19  | <b>SY1018</b> | MANIGLIA       | HANDLE         | POIGNEE        | GRIFF         | MANILLA        |
| 20  | <b>SY1019</b> | VASSOIO        | TRAY           | PLATEAU        | TABLETT       | BANDEA         |
| 21  | <b>SY1028</b> | FONDO          | BOTTOM         | FOND           | BODEN         | FONDO          |
| 22  | <b>SY1021</b> | SUPPORTO       | SUPPORT        | SUPPORT        | HALTER        | SOPORTE        |