




Pos	Codice	Italiano	English	Francais	Deutsch	Espanol
01	IC1042	COPERCHIO	COVER	COUVERCLE	DECKEL	TAPA
02	IC1002	CESTELLO	BASKET	PANIER	KORB	CESTO
03	IC1003	SPIA	WARNING LIGHT	TEMOIN LUMINEUX	KONTROLLEUCHTE	PILOTO
04	IC1026	GUSCIO ANT.	Front Protection	ENVELOPPE ANT.	GEHAEUSE VORN	VAINA ANT.
04A	IC1005	GUSCIO POST.	Rear Protection	ENVELOPPE Post.	GEHAEUSE HINTEN	VAINA POST.
05	IC1006	CAVO ALIMENTAZIONE	POWER SUPPLY CORD	CORDON D'ALIMENTATION	NETZKABEL	CABLE ALIMENTACION
06	IC1007	MICROINTERRUTTORE	MICROSWITCH	MICRORUPTEUR	MIKROSCHALTER	MICROINTERRUPTOR
07	IC1008	TERMOSTATO	THERMOSTAT	THERMOSTAT	THERMOSTAT	TERMOSTATO
08	IC1009	TERMOSTATO	THERMOSTAT	THERMOSTAT	THERMOSTAT	TERMOSTATO
09	IC1010	INTERRUTTORE	SWITCH	INTERRUPTEUR	SCHALTER	INTERRUPTOR
10	IC1012	BACINELLA	TRAY	BAC	SCHALE	CUBETA
11	IC1014	CONTENITORE	CONTAINER	RESERVOIR	BEHAELTER	CONTENEDOR
12	IC1015	IMPUGNATURA	HANDLE	POIGNEE	GRIFF	EMPUÑADURA
13	IC1016	PIEDINO	FOOT	PIED	FUSS	PIE
14	IC1017	IMPUGNATURA	HANDLE	POIGNEE	GRIFF	EMPUÑADURA
15	IC1018	MANOPOLA	KNOB	BOUTON	KNOPF	MANDO
16	IC1020	RESISTENZA	HEATING Element	ELEMENT Chauffant	HEIZELEMENT	RESISTENCIA
17	IC1021	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
21	IC1030	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
22	IC1029	TIMER	TIMER	PROGRAMMATEUR	ZEITSCHALTUHR	TIMER