




Pos	Codice	Italiano	English	Francais	Deutsch	Espanol
	567919	SCATOLA IMBALLO	CARTON PACKAGING	CARTON D'EMBALLAGE	VERPACKUNGSKARTON	CAJA EMBALAJE
	573191	ISTRUZIONI	INSTRUCTION BOOK	MODE D'EMPLOI	BEDIENUNGSANLEITUNG	ISTRUCCION
001	VT515136	PROTEZIONE	PROTECTION	PROTECTION	SCHUTZ	PROTECCION
002	VT515141	PROTEZIONE	PROTECTION	PROTECTION	SCHUTZ	PROTECCION
003	710381	APPOGGIO	SUPPORT	APPUI	STUETZE	APOYO
004	552244	TAPPO	STOPPER	BOUCHON	STOEPESEL	TAPON
005	535523	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
006	535520	LISTELLO	FILLET	LISTEL	LEISTE	LISTEL
007	592349	CARTER	CRANK CASE	ENVELOPPE	GEHAEUSE	CARTER
008	611885	ASTA	ROD	TIGE	STANGE	BARRA
009	592346	CRUSCOTTO	CONTROL PANEL	Tableau de Commande	BEDIENUNGSBLENDE	Marco Panel Mandos
010	622088	SERBATOIO	TANK	RESERVOIR	TANK	DEPOSITO
011	535526	TUBO	TUBE	TUBE	ROHR	TUBO
012	535524	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
013	521459	ELETTROVALVOLA	SOLENOID VALVE	Soupape Electrique	SOLENOIDVENTIL	Valvula Solenoide
015	521458	PRESSOSTATO	PRESSURE Switch	PRESSOSTAT	DRUCKWAECHTER	PRESOSTATO
016	622086	CALDAIA	BOILER	CHAUDIERE	HEIZKESSEL	CALDERA
017	521457	TERMOSTATO	THERMOSTAT	THERMOSTAT	THERMOSTAT	TERMOSTATO
018	512640	SPIA	WARNING LIGHT	TEMOIN LUMINEUX	KONTROLLEUCHTE	PILOTO
019	512641	SPIA	WARNING LIGHT	TEMOIN LUMINEUX	KONTROLLEUCHTE	PILOTO
020	512571	INTERRUTTORE	SWITCH	INTERRUPTEUR	SCHALTER	INTERRUPTOR
021	535934	TASTO	PUSH BUTTON	POUSOIR	TASTE	TECLA
022	535936	TASTO	PUSH BUTTON	POUSOIR	TASTE	TECLA
023	535935	TASTO BIANCO	Push Button White	POUSOIR BLANC	TASTE WEISS	TECLA BLANCO
024	535522	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
025	622087	SERBATOIO	TANK	RESERVOIR	TANK	DEPOSITO
026	535156	PIEDINO	FOOT	PIED	FUSS	PIE
028	535595	TUBO	TUBE	TUBE	ROHR	TUBO
029	534218	SERRACAVO	WIRE CLAMP	SERRE CABLE	KABELSCHELLE	GRAPA
030	521456	TERMOSTATO 140°	THERMOSTAT 140°	THERMOSTAT 140°	THERMOSTAT 140°	TERMOSTATO 140°
031	622085	CALDAIA	BOILER	CHAUDIERE	HEIZKESSEL	CALDERA
032	521460	SCHEDA	BOARD	FICHE	PLATINE	FICHA
033	VT515900	TUBO	TUBE	TUBE	ROHR	TUBO
034	552243	RUBINETTO	TAP	ROBINET	HAHN	GRIFO
035	535521	MANOPOLA	KNOB	BOUTON	KNOPF	MANDO
036	534956	SERRACAVO	WIRE CLAMP	SERRE CABLE	KABELSCHELLE	GRAPA
037	VT515400	FONDO	BOTTOM	FOND	BODEN	FONDO
038	592233	COPERCHIO	COVER	COUVERCLE	DECKEL	TAPA
039	VT505969	PIASTRA	PLATE	PLAQUE	PLATTE	PLACA
040	512299	TERMOSTATO 315°	THERMOSTAT 315°	THERMOSTAT 315°	THERMOSTAT 315°	TERMOSTATO 315°
041	512298	TERMOSTATO	THERMOSTAT	THERMOSTAT	THERMOSTAT	TERMOSTATO
042	707139	CALOTTA	COVER	CALOTTE	HAUBE	TAPA
043	534597	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
044	512264	SPIA	WARNING LIGHT	TEMOIN LUMINEUX	KONTROLLEUCHTE	PILOTO
045	534625	GEMMA ROSSA	RED LENS	LENTILLE ROUGE	LINSE ROT	PILOTO ROJO
046	690057	GIUNTO	JOINT	JOINT	KUPPLUNG	JUNTA
047	592560	MANOPOLA	KNOB	BOUTON	KNOPF	MANDO
048	VT505537	SCOCCA	BODY	CARROSSERIE	KASTEN	CARCASA
049	707140	STAFFA	BRACKET	ETRIER	BUEGEL	ABRAZADERA
050	534626	PASSACAVO	CABLE GROMMET	PASSE CABLE	KABELDURCHGANG	AISLADOR
051	501360	TUBO	TUBE	TUBE	ROHR	TUBO
052	VT505535	IMPUGNATURA	HANDLE	POIGNEE	GRIFF	EMPUÑADURA
053	535546	FLANGIA	FLANGE	BRIDE	FLANSCH	BRIDA
054	535948	FRONTALE	FRONT PANEL	PANNEAU AVANT	VORDERWAND	PARTE DELANTERA
055	535937	COPRITASTO	PUSH BUTTON COVER	COUVRE POUSSOIR	TASTENABDECKUNG	CUBRETECLA
056	512267	PULSANTE	PUSH BUTTON	POUSOIR	DRUCKKNOPF	BOTON