




Pos	Codice	Italiano	English	Francais	Deutsch	Espanol
01	VT205045	TASTO BIANCO	Push Button White	POUSSOIR BLANC	TASTE WEISS	TECLA BLANCO
02	5328106700	LISTELLO	FILLET	LISTEL	LEISTE	LISTEL
03	VT205044	FERMO	STOP	ARRET	SPERRUNG	TOPE
04	VT157339	INTERRUTTORE	SWITCH	INTERRUPTEUR	SCHALTER	INTERRUPTOR
05	5328101600	PULSANTE	PUSH BUTTON	POUSSOIR	DRUCKKNOPF	BOTON
06	5928105300	MANOPOLA	KNOB	BOUTON	KNOPF	MANDO
07	5928104600	CORPO	SHELL	CORPS	KOERPER	CUERPO
08	VT205004	PASSACAVO	CABLE GROMMET	PASSE CABLE	KABELDURCHGANG	AISLADOR
09	VT105150	MOLLA	SPRING	RESSORT	FEDER	MUELLE
10	VT205039	GUIDA	RUNNER	GLISSIERE	FUEHRUNG	GUIA
11	5128101700	SPIA	WARNING LIGHT	TEMOIN LUMINEUX	KONTROLLEUCHTE	PILOTO
12	5928100600	FONDO	BOTTOM	FOND	BODEN	FONDO
13	VT105196	ISOLANTE	INSULATOR	ISOLANT	ISOLIERSTOFF	AISLANTE
14	5328101500	CALOTTA	COVER	CALOTTE	HAUBE	TAPA
15	533213	O-RING	O-RING	JOINT OR	O-RING	O-RING
16	SC21110302	COPERCHIETTO	COVER	COUVERCLE	DECKEL	TAPADERA
17	SC26000040	SFERA	BALL	BILLE	KUGEL	ESFERA
18	5228102500	TERMOSTATO	THERMOSTAT	THERMOSTAT	THERMOSTAT	TERMOSTATO
19	SC21110349	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
20	SC31110315	COPERCHIO	COVER	COUVERCLE	DECKEL	TAPA
21	SC21110232	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
24	SC26600022	RACCORDO	CONNECTION	RACCORD	ANSCHLUSS	JUNTURA
26	SC25010028	TUBETTO	TUBE	TUBE	ROHR	TUBITO
27	7328108400	PIASTRA STIR.	IRONING PLATE	SEMELLE	SOHLE	PLACA
28	5928109800	TASTO	PUSH BUTTON	POUSSOIR	TASTE	TECLA
29	5128101000	SPIA VERDE	Green Warning Light	Temoin Lum. Verte	Kontrolleuchte GRUEN	Piloto Verde
30	SC6824830	GEMMA VERDE	GREEN LENS	LENTILLE VERTE	GRUENE LINSE	PILOTO VERDE
31	VT101526	INTERRUTTORE	SWITCH	INTERRUPTEUR	SCHALTER	INTERRUPTOR
32	SC29991333	PASSACAVO	CABLE GROMMET	PASSE CABLE	KABELDURCHGANG	AISLADOR
33	SC29991334	PASSACAVO	CABLE GROMMET	PASSE CABLE	KABELDURCHGANG	AISLADOR
34	5228100100	MANOMETRO	MANOMETER	MANOMETRE	DRUCKANZEIGER	MANOMETRO
36	5928109700	TASTO	PUSH BUTTON	POUSSOIR	TASTE	TECLA
37	7328113200	MANOPOLA	KNOB	BOUTON	KNOPF	MANDO
39	5528100300	CAVO	CABLE	CABLE	KABEL	CABLE
41	SC6404200	PIASTRINA	PLATE	PLAQUETTE	PLAETTCHEN	PLAQUITA
42	SC1771529	TERMOSTATO 145°	THERMOSTAT 145°	THERMOSTAT 145°	THERMOSTAT 145°	TERMOSTATO 145°
44	5228101600	TERMOSTATO 160°	THERMOSTAT 160°	THERMOSTAT 160°	THERMOSTAT 160°	TERMOSTATO 160°
44	SC29990077	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
45	SC39990090	RESISTENZA	HEATING Element	ELEMENT Chauffant	HEIZELEMENT	RESISTENCIA
49	5328108300	SCOCCA INF.	BODY LOWER	CARROSSERIE INF.	KASTEN UNTEN	CARCASA INF.
50	SC29993056	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
51	SC26010003	GOMMINO	RUBBER PAD	PARE CHOC	PUFFER	GUARNICION
52	SC5704100	BLOCCETTO	BLOCK	BLOC	STUECK	BLOQUE
53	7328102100	CALDAIA	BOILER	CHAUDIERE	HEIZKESSEL	CALDERA
54	6128101100	NIPPLE	NIPPLE	NIPPLE	NIPPEL	NIPLE
55	SC5174020	TUBETTO	TUBE	TUBE	ROHR	TUBITO
56	5228101700	PRESSOSTATO	PRESSURE Switch	PRESSOSTAT	DRUCKWAECHTER	PRESOSTATO
57	6191100900	RACCORDO	CONNECTION	RACCORD	ANSCHLUSS	JUNTURA
58	SC29993057	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
59	VT157332	FILTRO RETE	NOISE FILTER	FILTRE Antiparasites	ENTSTOERFILTER	FILTRO
61	SC1770225	INTERRUTTORE	SWITCH	INTERRUPTEUR	SCHALTER	INTERRUPTOR
62	SC5654790	TAPPO	STOPPER	BOUCHON	STOEPSSEL	TAPON
63	SC5654800	PISTONE	PISTON	PISTON	KOLBEN	PISTON
64	SC5654780	BASE	SUPPORT BASE	BASE D'APPUI	STUETZFLAECH	SOPORTE
65	SC5174800	ELETTROVALVOLA	SOLENOID VALVE	Soupape Electrique	SOLENOIDVENTIL	Valvula Solenoide
68	SC29991056	SERRACAVO	WIRE CLAMP	SERRE CABLE	KABELSCHELLE	GRAPA
69	5128100900	SPIA	WARNING LIGHT	TEMOIN LUMINEUX	KONTROLLEUCHTE	PILOTO
70	SC6824840	GEMMA ARANCIO	ORANGE LENS	LENTILLE ORANGE	Dunkelorange LINSE	PILOTO Anaranjado
71	5928109900	SCOCCA SUP.	BODY UPPER	CARROSSERIE sup.	KASTEN OBEN	CARCASA SUP.
72	VT257031	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
74	7328115300	TAPPO	STOPPER	BOUCHON	STOEPSSEL	TAPON
75	7328110300	TAPPETO	RUBBER CARPET	TAPIS	GUMMITTEPPICH	Alfombra de Caucho
76	7328113300	COPERTURA	COVER	COUVERTURE	VERSCHLUSS	REVESTIMIENTO
77	5328105200	IMBUTO	FUNNEL	ENTONNOIR	TRICHTER	EMBUDO