




Pos	Codice	Italiano	English	Francais	Deutsch	Espanol
	AX1041	SCATOLA	BOX	BOITE	ABDECKUNG	CAJA
	AX1044	ISTRUZIONI	INSTRUCTION BOOK	MODE D'EMPLOI	BEDIENUNGSANLEITUNG	ISTRUCCION
01	AX1000	GUSCIO	PROTECTION	ENVELOPPE	GEHAEUSE	VAINA
02	AX1001	GUSCIO	PROTECTION	ENVELOPPE	GEHAEUSE	VAINA
03	AX1004	MOTORE	MOTOR	MOTEUR	MOTOR	MOTOR
04	AX1005	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
05	AX1006	BATTERIA	BATTERY	CARCASSE	HEIZKOERPER	BATERIA
06	AX1007	GIRANTE	IMPELLER	COURONNE	LAUFRAD	MOBILE ROTOR
07	AX1008	CHIUSURA	CLOSURE	FERMETURE	VERSCHLUSS	CIERRE
08	AX1009	CURSORE	SLIDER	CURSEUR	SCHIEBER	CURSOR
09	AX1010	COPERCHIETTO	COVER	COUVERCLE	DECKEL	TAPADERA
10	AX1011	SCHEDA	BOARD	FICHE	PLATINE	FICHA
11	AX1012	SPINOTTO	GUDGEON PIN	FICHE	STECKER	PERNO
12	AX1013	SCHEDA	BOARD	FICHE	PLATINE	FICHA
13	AX1014	MOLLA	SPRING	RESSORT	FEDER	MUELLE
14	AX1015	PULSANTE	PUSH BUTTON	POUSOIR	DRUCKKNOPF	BOTON
15	AX1016	FILTRO	FILTER	FILTRE	FILTER	FILTRO
16	AX1017	CHIUSSURA	CLOSURE	FERMETURE	VERSCHLUSS	CIERRE
18	AX1020	FRONTALE	FRONT PANEL	PANNEAU AVANT	VORDERWAND	PARTE DELANTERA
19	AX1023	BOCCHETTA	VENT	SUCEUR	DUESE	BOQUILLA
20	AX1026	SPAZZOLA	BRUSH	BROSSE	BUERSTE	CEPILLO
21	AX1029	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
22	AX1030	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
23	AX1047	SQUADRETTA	BRACKET	EQUERRE	WINKEL	ESCUADRA
24	AX1048	ADATTATORE	ADAPTER	ADAPTATEUR	PASSTUECK	ADAPTADOR