




Pos	Codice	Italiano	English	Francais	Deutsch	Espanol
	PS1012	ISTRUZIONI	INSTRUCTION BOOK	MODE D'EMPLOI	BEDIENUNGSANLEITUNG	ISTRUCCION
	PS1053	SCATOLA IMBALLO	CARTON PACKAGING	CARTON D'EMBALLAGE	VERPACKUNGSKARTON	CAJA EMBALAJE
001	PS1001	LEVA	LEVER	LEVIER	HEBEL	PALANCA
002	PS1002	TUBO FLESSIBILE	FLEXIBLE TUBE	TUBE FLESSIBLE	SCHLAUCH	TUBO FLEXIBLE
003	PS1003	*ESAURITO	*NOT AVAILABLE	*PLUS DISPONIBLE	*NICHT VERFUEGBAR	*AGOTADO
004	PS1004	TUBO FLESSIBILE	FLEXIBLE TUBE	TUBE FLESSIBLE	SCHLAUCH	TUBO FLEXIBLE
005	PS1005	BOCCHETTA	VENT	SUCEUR	DUESE	BOQUILLA
006	PS1006	SPAZZOLA	BRUSH	BROSSE	BUERSTE	CEPILLO
007	PS1007	SPAZZOLA	BRUSH	BROSSE	BUERSTE	CEPILLO
008	PS1008	SPAZZOLA	BRUSH	BROSSE	BUERSTE	CEPILLO
009	PS1009	SPORTELLINO	DOOR	PORTILLON	KLAPPE	PORTILLO
010	PS1010	FLANGIA	FLANGE	BRIDE	FLANSCH	BRIDA
011	PS1011	LINGUETTA	TAB	LANGUETTE	LASCHE	LENGÜETA
013	PS1013	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
014	PS1014	SACCO	BAG	SAC	BEUTEL	SACO
015	PS1015	CORPO	SHELL	CORPS	KOERPER	CUERPO
016	PS1016	COPERTURA	COVER	COUVERTURE	VERSCHLUSS	REVESTIMIENTO
017	PS1017	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
018	PS1018	MOTORE	MOTOR	MOTEUR	MOTOR	MOTOR
019	PS1019	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
020	PS1020	SCHEDA	BOARD	FICHE	PLATINE	FICHA
021	PS1021	PARACOLPI	BUMPER	PARE CHOC	PUFFER	PARAGOLPES
022	PS1022	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
023	PS1023	BASAMENTO	BASE	SOCLE	UNTERGESTELL	BASE
024	PS1024	RUOTA	CASTOR	ROULETTE	RAD	RUEDA
025	PS1025	COPERCHIO	COVER	COUVERCLE	DECKEL	TAPA
026	PS1026	MOLLA	SPRING	RESSORT	FEDER	MUELLE
027	PS1027	GANCIO	HOOK	CROCHET	HAKEN	GANCHO
028	PS1028	ANELLO	RING	ANNEAU	RING	ANILLO
029	PS1029	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
030	PS1030	PROTEZIONE	PROTECTION	PROTECTION	SCHUTZ	PROTECCION
031	PS1031	SCHEDA	BOARD	FICHE	PLATINE	FICHA
032	PS1032	PROFILO	PROFILE	PROFIL	LEISTE	PERFIL
033	PS1033	MANIGLIA	HANDLE	POIGNEE	GRIFF	MANILLA
034	PS1034	INTERRUTTORE	SWITCH	INTERRUPTEUR	SCHALTER	INTERRUPTOR
035	PS1035	MASCHERINA	TEMPLATE	PLAQUE	BLENDE	PLANTILLA
036	PS1036	SUPPORTO	SUPPORT	SUPPORT	HALTER	SOPORTE
037	PS1037	COPERCHIETTO	COVER	COUVERCLE	DECKEL	TAPADERA
038	PS1038	TASTO	PUSH BUTTON	POUSSOIR	TASTE	TECLA
039	PS1039	TASTO	PUSH BUTTON	POUSSOIR	TASTE	TECLA
040	PS1040	PERNO	PIN	PIVOT	STIFT	PERNO
041	PS1041	MOLLA	SPRING	RESSORT	FEDER	MUELLE
042	PS1042	SCHEDA	BOARD	FICHE	PLATINE	FICHA
043	PS1043	AVVOLGICAVO	CABLE WINDER	ENROULEUR	KABELAUFWICKLUNG	De Cable Recogecables
044	PS1044	RUOTA	CASTOR	ROULETTE	RAD	RUEDA
045	PS1045	ASTA	ROD	TIGE	STANGE	BARRA
046	PS1046	MOLLA	SPRING	RESSORT	FEDER	MUELLE
047	PS1047	PASSACAVO	CABLE GROMMET	PASSE CABLE	KABELDURCHGANG	AISLADOR
048	PS1048	RUOTA	CASTOR	ROULETTE	RAD	RUEDA
049	PS1049	ISOLANTE	INSULATOR	ISOLANT	ISOLIERSTOFF	AISLANTE
050	PS1050	FONDO	BOTTOM	FOND	BODEN	FONDO
051	PS1051	GANCIO	HOOK	CROCHET	HAKEN	GANCHO
052	PS1052	GRIGLIA	GRID	GRILLE	GITTER	PARRILLA
054	PS1054	FILTRO	FILTER	FILTRE	FILTER	FILTRO
055	PS1055	FILTRO	FILTER	FILTRE	FILTER	FILTRO